


SPARE PARTS BODY AND LI FTI NG ARM

Page 1 of 4




88 SPARE PARTS-MOV

Code	Description
LC588. 05. 11	Gui de bracket
	Screw
	Screw
	Flat washer
	Elastic washer
	Nut
LC588. 04. 13	Washer
LC588. 05. 00	Frame
LC588. 04. 12	Arm shaft
	Flat washer
	Screw
LC588. 06. 00	Slide table with roller
	Flat washer
	Screw
	Screw
LC588. 06. 05	Rolling wheel
	Locknut
LC588. 04. 04	Washer
LC588. 04. 05	Nut cover

SPARE PARTS- MOUNTING PLATE AND VERTICAL ARM


Page 2 of 4



SPARE PARTS SHAFT CONTROL CYLINDER AND CLAMPING DEVICE
Page 3 of 4

Ref.	Code	Description	Specification	Qty	Note
301	LC588.00.13	Union	M4X1.5 S19	2	
302	LC588.00.22	O1 pipe A	φ 12 dia (inside) outside φ 8	2	
303		Revolving union complete	M4X1.5	1	
304		Washer	φ 14	2	
305	LC588.00.16	Gauge union	M4X1.5 S22	1	
306	LC588.00.16A	Washer	φ 12	1	
307		Gauge	Dia. 63mm 0-250bar	1	
308	LC588.00.18	Locknut	M4X1.5 S17	1	
309		Spacer	φ 8	1	
310	LC588.00.15	Union	M4X1.5 S19	1	
311		O ring	φ 25 (inside) X3.55	1	
312	LC588.00.19	Union	M4X1.5 S22	1	
313	LC588.00.20	Union		1	
314	LC588.03.01.00	Cylinder body	Dia φ 95, stroke 105	1	
315		Screw	M6X10	1	
316		Nut	M4X2	1	
317		Sealing parts	DAS095X75	1	
318	LC588.03.02	Piston		1	
319		O ring	φ 25 (outside) X2.65	2	
320	LC588.03.03	Shaft of cylinder	φ 35	1	
321		O ring	φ 101 (outside) X3.55	1	
322		Seeger ring	53#	1	
323	LC588.03.05	Spacer		1	
324		Y sealing ring	35X43X12	1	
325		O ring	φ 40 (outside) X2.65	1	
326	LC588.03.04	Cylinder front housing	M4X2	1	
327		Screw	M6X25	12	
328	LC588.07.05A	Rear housing for gearbox		1	
329	LC588.07.07A	Paper washer	δ 0.3	2	
330	LC588.07.01A	Gearbox		1	
331		O ring	φ 10 (内径) X3.15	2	
332		Screw	M0X16	2	
333		Flat washer	10	6	
334		Screw	M0X45	6	
335	LC588.03.17	Adjusting washer	δ 0.5	2	
336	LC588.03.15A	Adjusting washer	δ 9	1	
337	LC588.07.02A	Wormwheel	Z=100, M3	1	
338	LC588.07.04.01A	Gearbox housing		1	
339		O1 filter warning light	M27X1.5	1	
340	LC588.07.08A	Support iron		2	
341		Screw	M6X10	4	
342		Screw	M6X25	12	
343		Bearing	30205	2	
344	LC588.07.03A	Wormrod	M3, φ 42	1	
345	LC588.07.06A	Gearbox front housing		1	
346	LC588.07.09A	Pulley	A model	1	
347		Disk key	8X35	1	
348	LC588.07.10	Seeger ring		1	
349		Screw	M8X20	1	
350		Belt	A750	2	
351	LC588.03.06	Spacer		1	
352	LC588.03.06.00	Shaft frame		1	
353		Disk key	20X50	1	
354		Screw	M6X10	8	
355		Flat washer		8	
356	LC588.03.19	Plate		4	
357		Screw	M4X80	12	
358		Flat washer	14	12	
359	LC588.03.10	Roller	φ 40	4	
360	LC588.03.12.00	Jaw support		4	
361		Locknut	M4	12	
362	LC588.03.18	Jaw		4	
363	LC588.03.07	Protection cover		1	
364	LC588.03.08	Plate	δ 24, φ 190	1	
365	LC588.03.09.00	Bracket		1	
366		Locknut	M4X2	1	

SPARE PARTS-SHAFT AND CLAMPING DEVICE



SPARE PARTS-ELECTRICAL PARTS

Page 4 of 4

